

THER 小徑刀把 THER SLIM COLLET CHUCK



BT JIS B6339 (MAS 403 BT)

Balancing / 動平衡		Dimensions / 尺寸標示	
<p>G6.3</p> <p>BT30 / BT40 Max.25,000 RPM Or U ≤ 1gmm</p>	<p>G6.3</p> <p>BT50 Max.20,000 RPM Or U ≤ 1gmm</p>		
<p>Option / 選配 G2.5</p> <p>BT30 / BT40 Max.25,000 RPM Or U ≤ 1gmm</p>	<p>Option / 選配 G2.5</p> <p>BT50 Max.20,000 RPM Or U ≤ 1gmm</p>		

Order No. 訂購編號	Range 夾持範圍	ød	ød1	ød2	L	L1	L2	Tool Clamping Depth L3 刀具夾持 深度	page.146 Nut 螺帽	page.144 Screw 調整螺絲	page.120 Collet 筒夾	page.149 Wrench 扳手
BT30 (BTT30)	THER11-100	1.0~7.0	16	20.9	100	78	73.2	19~48	CAP-THER11	ER-M8	ER11-HP	PHS-20-RO160
	THER16-100	1.0~10.0	22	26.5	100	78	73.2	29~58	CAP-THER16	ER-M11	ER16-HP	PHS-20-RO220
BT40 (BTT40)	THER11-100	1.0~7.0	16	20.2	100	73	65.3	19~48	CAP-THER11	ER-M8	ER11-HP	PHS-20-RO160
	THER11-130	1.0~7.0	16	22.8	130	103	95.3	19~48	CAP-THER11	ER-M8	ER11-HP	PHS-20-RO160
	THER11-160	1.0~7.0	16	25.5	160	133	125.3	19~48	CAP-THER11	ER-M8	ER11-HP	PHS-20-RO160
	THER16-100	1.0~10.0	22	26.1	100	73	68.2	29~58	CAP-THER16	ER-M11	ER16-HP	PHS-20-RO220
	THER16-130	1.0~10.0	22	28.7	130	103	98.2	29~58	CAP-THER16	ER-M11	ER16-HP	PHS-20-RO220
	THER16-160	1.0~10.0	22	31.3	160	133	128.2	29~58	CAP-THER16	ER-M11	ER16-HP	PHS-20-RO220
BT50 (BTT50)	THER11-100	1.0~7.0	16	18.7	100	62	47.7	19~48	CAP-THER11	ER-M8	ER11-HP	PHS-20-RO160
	THER11-130	1.0~7.0	16	21.3	130	92	77.7	19~48	CAP-THER11	ER-M8	ER11-HP	PHS-20-RO160
	THER11-160	1.0~7.0	16	23.9	160	122	107.7	19~48	CAP-THER11	ER-M8	ER11-HP	PHS-20-RO160
	THER16-100	1.0~10.0	22	24.3	100	62	47.7	29~58	CAP-THER16	ER-M11	ER16-HP	PHS-20-RO220
	THER16-130	1.0~10.0	22	26.9	130	92	77.7	29~58	CAP-THER16	ER-M11	ER16-HP	PHS-20-RO220
	THER16-160	1.0~10.0	22	29.5	160	122	107.7	29~58	CAP-THER16	ER-M11	ER16-HP	PHS-20-RO220

Remarks / 備註

- 需配合 3μ HP 筒夾 With 3μ HP Grade Collet
- 若需出水型刀把，請參考 page.26 選用說明
- 筒夾夾持為一對一整數值

Applications / 應用

