


SPARE PARTS

止水環
Sealing Disk

SPARE PARTS


Model	øD	L	配合螺帽	配合筒夾	訂購編號 Order No.
HER16	12.6	2	CAP-HER16MC CAP-HER16C	ER16-HP	HER16-1R
					HER16-1.5R
					HER16-2R
					HER16-2.5R
					HER16-3R
					HER16-3.5R
					HER16-4R
					HER16-4.5R
					HER16-5R
					HER16-5.5R
					HER16-6R
					HER16-6.5R
					HER16-7R
					HER16-7.5R
					HER16-8R
					HER16-8.5R
					HER16-9R
					HER16-9.5R
					HER16-10R



Model	øD	L	配合螺帽	配合筒夾	訂購編號 Order No.
HER20	15.8	2	CAP-HER20C	ER20-HP	HER20-2R
					HER20-2.5R
					HER20-3R
					HER20-3.5R
					HER20-4R
					HER20-4.5R
					HER20-5R
					HER20-5.5R
					HER20-6R
					HER20-6.5R
					HER20-7R
					HER20-7.5R
					HER20-8R
					HER20-8.5R
					HER20-9R
					HER20-9.5R
					HER20-10R
					HER20-10.5R
					HER20-11R
					HER20-11.5R
					HER20-12R
					HER20-12.5R
					HER20-13R

Model	øD	L	配合螺帽	配合筒夾	訂購編號 Order No.
HER25	20.2	2	CAP-HER25C	ER25-HP	HER25-2R
					HER25-2.5R
					HER25-3R
					HER25-3.5R
					HER25-4R
					HER25-4.5R
					HER25-5R
					HER25-5.5R
					HER25-6R
					HER25-6.5R
					HER25-7R
					HER25-7.5R
					HER25-8R
					HER25-8.5R
					HER25-9R
					HER25-9.5R
					HER25-10R
					HER25-10.5R
					HER25-11R
					HER25-11.5R
					HER25-12R
					HER25-12.5R
					HER25-13R
					HER25-13.5R
					HER25-14R
					HER25-14.5R
					HER25-15R
					HER25-15.5R
					HER25-16R

止水環 Sealing Disk



Model	øD	L	配合螺帽	配合筒夾	訂購編號 Order No.
HER32	26.2	2	CAP-HER32C	ER32-HP	HER32-2R
					HER32-2.5R
					HER32-3R
					HER32-3.5R
					HER32-4R
					HER32-4.5R
					HER32-5R
					HER32-5.5R
					HER32-6R
					HER32-6.5R
					HER32-7R
					HER32-7.5R
					HER32-8R
					HER32-8.5R
					HER32-9R
					HER32-9.5R
					HER32-10R
					HER32-10.5R
					HER32-11R
					HER32-11.5R
					HER32-12R
					HER32-12.5R
					HER32-13R
					HER32-13.5R
					HER32-14R
					HER32-14.5R
					HER32-15R
					HER32-15.5R
					HER32-16R
					HER32-16.5R
					HER32-17R
					HER32-17.5R
					HER32-18R
					HER32-18.5R
					HER32-19R
					HER32-19.5R
					HER32-20R

Model	øD	L	配合螺帽	配合筒夾	訂購編號 Order No.
HER16	12.6	2	CAP-HER16MC CAP-HER16C	ER16-HP	HER16-1/8"R
					HER16-3/16"R
					HER16-1/4"R
					HER16-5/16"R
					HER16-3/8"R

Model	øD	L	配合螺帽	配合筒夾	訂購編號 Order No.
HER32	26.2	2	CAP-HER32C	ER32-HP	HER32-1/8"R
					HER32-3/16"R
					HER32-1/4"R
					HER32-5/16"R
					HER32-3/8"R
					HER32-1/2"R
					HER32-5/8"R
					HER32-3/4"R

SPARE PARTS